



TO SET PROGRAM

1. Pull **UP** trippers on dial to set desired **ON** times.
2. Turn dial clockwise until the time of day is adjacent to **TIME** arrow.

IN CASE OF POWER FAILURE RESET TIMER.



CONTACT RATINGS: SPST
 20 AMP. "R" 120-277 VAC, 1800 W.
 (15A) "T", 120 VAC, 1 H.P. - 120 VAC
 2 HP - 240 VAC, 360 VA 120/240 VAC



LR3730

CONTACT RATINGS: SPST
 16 AMP "R" 120-277 VAC, 1800 W.
 (15A) "T" 120 VAC, 1 H.P. -120 VAC,
 2 H.P. -240 VAC, 360 VA 120/240 VAC.

MODEL NO: PB913UB66
CLOCK MOTOR VOLTAGE: 125V

INTERMATIC INCORPORATED
 SPRING GROVE, ILLINOIS 60081-9698
 PRODUCT OF MEXICO